


1 Plug power connector into InVue product and merchandise.

2 Plug adapter into InVue product and OEM power supply.



ORDER CODE	DESCRIPTION	VOLTS
CFTN21B	FP Power Connector – Tablet 2.0 mm Barrel	12 Volts
CFTN25B	FP Power Connector – Tablet 2.5 mm Barrel	12 Volts
CFTN26B	FP Power Connector – Tablet 2.5 mm Barrel	9 Volts
CFTN27B	FP Power Connector – Tablet 2.5 mm Barrel	5 Volts
CFTN30B	FP Power Connector – Tablet 3.0 mm Barrel	5 Volts
CFTN31B	FP Power Connector – Tablet 3.0 mm Barrel	12 Volts
CFTN32B	FP Power Connector – Tablet 3.0 mm Barrel	19 Volts
CFTN35B	FP Power Connector – Tablet 3.5 mm Barrel	5 Volts
CFTN37B	FP Power Connector – Tablet 3.5 mm Barrel	12 Volts
CFTN38B	FP Power Connector – Tablet 3.5 mm Barrel	19 Volts
CFTN40B	FP Power Connector – Tablet 4.0 mm Barrel	5 Volts
CFTN41B	FP Power Connector – Tablet 4.0 mm Barrel	9 Volts
CFTN42B	FP Power Connector – Tablet 4.0 mm Barrel	12 Volts
CFTN43B	FP Power Connector – Tablet 4.0 mm Barrel	19 Volts